

MI-TFPT-X

MI TIMED FLOW PILLAR TAP



INSTALLATION

Installation must be carried out in accordance with the AS3500 Series, the NCC Volume 3 and any other local authority requirements.

Flush all supply lines thoroughly ensuring to remove all dirt and foreign matter.
Install tap into basin or hob, tightening the fixing nut with either a shifter or multi-grips.

Ensure the tap is firmly attached to the basin or hob surface.

Connect the 15mm BSP inlet to water supply line.

After a successful connection, remove tap aerator and flush the tap, once flushed replace aerator.

TECHNICAL DATA


150-350kPa water inlet pressure – If inlet water pressure exceeds 350kPa a pressure limiting/reducing valve must be fitted.

0-60 degree water inlet temperature

7 second run time

Warranty – 12 Months – Product warranty will be void if tap is installed outside of these parameters

DIMENSIONS



WARRANTY STATEMENT

MacDonald Industries' goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

All items must be installed as per manufacturers installation instructions and the AS3500 Series, the NCC Volume 3 and any other local authority requirements.

MacDonald Industries' standard warranty is 90 days on all labour and 12 months on parts.

The warranty does not extend to goods that are misused, installed incorrectly, damaged in any way by a third party beyond the control of MacDonald Industries, or where goods have not been maintained.

Should the Purchaser need to make a claim under the warranty then they must first contact MacDonald Industries notifying MacDonald Industries that it seeks to make a claim.

The contact details for MacDonald Industries are: sales@macdonaldindustries.com.au.

All goods are to be returned to MacDonald Industries at the Purchaser's expense to enable any warranty to be undertaken.

Any warranty work will only be carried out during normal working hours. Should this not be possible or practical, extra charges for labour will apply.

MACDONALD INDUSTRIES AUSTRALIA LIMITED

INSTALLATION INSTRUCTIONS



MACDONALD
INDUSTRIES AUSTRALIA

Melbourne (Head Office)

4/168 Jersey Drive, Epping

Victoria 3076

sales@macdonaldindustries.com.au

macdonaldindustries.com.au